



# Get to Know Your Phone

Para la versión en español, visite [verizonwireless.com/support](http://verizonwireless.com/support).

**LG LANCET™**  
for Android™

## About Your Phone



NOTE: Devices and software are constantly evolving—the screen images and icons you see here are for reference only.

## Setting Up Your Phone

Your phone comes with the SIM card pre-installed.

**Step 1. Remove the Back Cover**  
Place your fingernail in the USB/charger port cutout at the bottom of the phone and pop the cover off the phone.




**Optional: Insert the microSD Card**  
If you have a microSD card, slide the microSD card into the microSD card slot with the gold contacts facing down.

NOTE: The microSD card is sold separately.



**Step 2. Insert the Battery**  
Insert the battery, making sure to align the gold contacts. Press down gently to secure the battery.



**Step 3. Replace the Back Cover**  
Place the back cover over the back of the phone and then press down along the edges to secure the cover.



**Step 4. Charge Your Phone**  
Before turning on your phone, charge it fully. Be sure to use the USB cable and charger adapter that came with your phone.

WARNING! Please use only an approved charging accessory to charge your phone. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty shown.



MBM65281401 (1.0)  
This booklet is made from 100% post-consumer recycled paper.  
This booklet is printed with soy ink. Printed in China

© 2015 Verizon Wireless. All Rights Reserved.



## Using Your Phone

### Turning Your Phone On/Off

To turn your phone on, press and hold the **Power/Lock** key.

To turn your phone off, press and hold the **Power/Lock** key until the Phone options are shown. Tap **Power off** > **OK**.

### Locking/Unlocking the Screen

To turn on your screen, quickly double-tap it, or press the **Power/Lock** key. Then swipe the screen up to unlock it.

You can also drag an app shortcut icon at the bottom of the screen in any direction to open the app.

To turn off your screen and prevent accidental key presses, press the **Power/Lock** key.

### Home Screen Mode

You can select one of the two modes: **Home** and **EasyHome**. Instructions in this guide are written based on **Home mode**.

**Home mode**—Standard experience for users who are familiar with Android.

**EasyHome mode**—Simplified and easier experience for the first-time smartphone user.

1.  >  From the Home screen, tap **Apps** > **Settings** > **Home screen** > **Select Home**.
2. Choose the mode you want to use.

### Advanced Calling

You can make High-Definition Voice and Video Calls, and surf the web while you talk on the phone, when you add Advanced Calling to your line. Visit [verizonwireless.com/AdvancedCalling](http://verizonwireless.com/AdvancedCalling) to learn how.

### Copying Content from Your Old Phone

For help transferring contacts, photos and other content from your old phone, visit [verizonwireless.com/cloud](http://verizonwireless.com/cloud).

## Learning More



The Help app gives you tips, videos and other information on how to use your phone, including:



Making Calls



Voice Mail



Sending Texts



Getting Apps



Taking Photos



Accessibility Settings



From your computer, visit [verizonwireless.com/support](http://verizonwireless.com/support).



Download a User Guide from [verizonwireless.com/support](http://verizonwireless.com/support) or call (877) 268-7589 to order a copy.

## Managing Your Account

### My Verizon Mobile App



Manage your account, track your usage, edit account information, pay your bill and more.

### International Travel



For features and rates when traveling outside the US, visit [verizonwireless.com/international](http://verizonwireless.com/international).

### Customer Service



Call (800) 922-0204.

Follow us @VZWSupport. 

## Additional Information

### Your Wireless Device and Third-Party Services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

### Hearing Aid Compatibility Information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.